



## Microwave Oven

The safety regulations:


- ✓ Never close lids on jars and boxes completely
- ✓ Eggs in a cup can't be heated in the oven
- ✓ Food with a shell must be pierced first before heated
- ✓ Never use the machine on microwave when it's empty
- ✓ Never use any metal in the microwave, this can give sparks and will damage the machine.

### Control Microwave function

1. Press the 'MICROWAVE' button to select the microwave function.
2. Turn the 'TIMER/WEIGHT' control knob. Set the cooking time..
3. Press the 'START/+30SEC./CONFIRM' button to start the set programme.

Microwave power level table:

Power	Press the 'MICROWAVE' button
100%	1x
80%	2x
50%	3x
30%	4x
10%	5x



### Control oven function

1. Press the 'GRILL/CONV./COMBI' button once. G-1 flashes.
2. Turn the 'TIMER/WEIGHT' control knob to the right. Select the hot-air function. Set the desired temperature (the temperature can be set between 140 and 230 °C).
3. Press the 'START/+30SEC./CONFIRM' button to confirm the temperature setting.\
4. Press the 'START/+30SEC./CONFIRM' button to start the set programme.

*Two beeps will sound when the preheating temperature is achieved. The temperature can be seen flashing in the display.*

5. Place the meal in the oven and close the door. Turn the 'TIMER/WEIGHT' control knob. Set the cooking time (the maximum cooking time is 95 minutes).
6. Press the 'START/+30SEC./CONFIRM' button to start the set programme.

